



Installation diagramme overview on Prima access control system



Installation diagramme for Alpha® 2 and 4 door centrals (incl. installation of a "standard" Nexus® reader)



Important:

The central's pre-loaded IP-address is written on the sticker on the backside of the central

BEFORE installation please contact your IT/network administrator to get usable IP-addresses

Installation diagramme for Alpha® 2 or 4 + PoE centrals

(only extra functions are shown on the central)

+ installation of 2 readers in one cable and a Nexus® P reader with external antenna

